


INSTALLATION INSTRUCTIONS

13 SEER SERIES CUBE HEAT PUMPS 1½ - 5 TONS



This product utilizes a compressor that is pre-charged with POE Oil.

This product is shipped with a nitrogen holding charge that must be vented prior to evacuation and charging and is identified by a tag on the unit shipping carton and on one of the unit service valves.

This product is only intended for heat pump change-out in existing R-22 systems with a matched indoor unit.

This product must be charged with R-22 refrigerant meeting AHRI 700 purity standard.

NOTE: Appearance of unit may vary.



RECOGNIZE THIS SYMBOL AS AN INDICATION OF IMPORTANT SAFETY INFORMATION!

⚠ WARNING

THESE INSTRUCTIONS ARE INTENDED AS AN AID TO QUALIFIED, LICENSED SERVICE PERSONNEL FOR PROPER INSTALLATION, ADJUSTMENT AND OPERATION OF THIS UNIT. READ THESE INSTRUCTIONS THOROUGHLY BEFORE ATTEMPTING INSTALLATION OR OPERATION. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN IMPROPER INSTALLATION, ADJUSTMENT, SERVICE OR MAINTENANCE POSSIBLY RESULTING IN FIRE, ELECTRICAL SHOCK, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



DO NOT DESTROY THIS MANUAL

PLEASE READ CAREFULLY AND KEEP IN A SAFE PLACE FOR FUTURE REFERENCE BY A SERVICEMAN



TABLE OF CONTENTS

1.0	SAFETY INFORMATION	3
2.0	GENERAL INFORMATION	4
2.1	checking product received	4
2.2	Applications	5
2.3	Dimensions	5
2.4	electrical and physical Data	6
3.0	LOCATING UNIT	6
3.1	corrosive environment	6
3.2	Heat pump Location	7
3.3	operational issues	7
3.4	units With Space Limitations	7
3.5	customer Satisfaction issues	7
3.6	unit mounting	8
3.7	factory-preferred tie-Down method	8
4.0	REFRIGERANT CONNECTIONS	10
5.0	REPLACEMENT UNITS	10
6.0	INDOOR COIL	10
6.1	Location	10
7.0	INTERCONNECTING TUBING	10
7.1	vapor & Liquid Lines	10
7.2	maximum Length of Lines	10
7.3	outdoor unit installed Above indoor coil	11
7.4	outdoor unit installed Below indoor coil	11
7.5	tubing installation	11
7.6	tubing connections	12
7.7	Leak testing	12
8.0	DEMAND DEFROST CONTROL	14
8.1	Defrost initiation	14
8.2	Defrost termination	14
8.3	temperature Sensors	14
8.4	test mode	15
8.5	Demand Defrost operation	15
8.6	trouble Shooting Demand Defrost	15
9.0	EvACUATION PROCEDURE	15
10.0	START UP & PERFORMANCE	16
11.0	CHECKING AIRFLOW	16
12.0	CHECKING REFRIGERANT CHARGE	16
12.1	charging By Liquid pressure	16
12.2	charging By Weight	17
12.3	final Leak testing	17
13.0	ELECTRICAL WIRING	17
13.1	power Wiring	17
13.2	Grounding	17
13.3	control Wiring	18
14.0	FIELD INSTALLED ACCESSORIES	18
14.1	compressor crankcase Heat	18
14.2	Low Ambient control	19
14.3	High pressure control	19
15.0	SERVICE	19
15.1	Single pole compressor contactor	19
16.0	TROUBLESHOOTING	20
16.1	electrical checks flow chart	20
16.2	cooling mechanical checks flow chart	21
16.3	Heating mechanical checks flow chart	22
16.4	Defrost mechanical checks flow chart	23
16.5	Subcooling calculation	24
16.6	General troubleshooting chart	25
16.7	Service Analyzer chart	26
17.0	WIRING DIAGRAMS	31

1.0 SAFETY INFORMATION

WARNING

Disconnect all power to unit before starting maintenance. Failure to do so can cause electrical shock resulting in severe personal injury or death.

WARNING

Turn off electric power at the fuse box or service panel before making any electrical connections.

Also, the ground connection must be completed before making line voltage connections. Failure to do so can result in electrical shock, severe personal injury or death.

WARNING

These instructions are intended as an aid to qualified licensed service personnel for proper installation, adjustment and operation of this unit. Read these instructions thoroughly before attempting installation or operation. Failure to follow these instructions may result in improper installation, adjustment, service or maintenance possibly resulting in fire, electrical shock, property damage, personal injury or death.

WARNING

The unit must be permanently grounded. Failure to do so can cause electrical shock resulting in severe personal injury or death.

WARNING

The manufacturer's warranty does not cover any damage or defect to the heat pump caused by the attachment or use of any components, accessories or devices (other than those authorized by the manufacturer) into, onto or in conjunction with the heat pump. You should be aware that the use of unauthorized components, accessories or devices may adversely affect the operation of the heat pump and may also endanger life and property. The manufacturer disclaims any responsibility for such loss or injury resulting from the use of such unauthorized components, accessories or devices.

CAUTION

When coil is installed over a finished ceiling and/or living area, it is recommended that a secondary sheet metal condensate pan be constructed and installed under entire unit. Failure to do so can result in property damage.

CAUTION

Single-pole contactors are used on all standard single-phase units up through 5 tons. Caution must be exercised when servicing as only one leg of the power supply is broken with the contactor.

CAUTION

Dual fuel (fossil fuel) applications require the use of a high pressure control in the heat pump section. If a high pressure control was not originally provided with the heat pump section from the factory, a factory approved high pressure control kit must be purchased from the manufacturer and installed in the heat pump. Dual fuel (fossil fuel) applications in which a high pressure control is not installed in the outdoor heat pump section will void the safety approval of the product.

2.0 GENERAL

WARNING

The manufacturer's warranty does not cover any damage or defect to the heat pump caused by the attachment or use of any components. Accessories or devices (other than those authorized by the manufacturer) into, onto or in conjunction with the heat pump. You should be aware that the use of unauthorized components, accessories or devices may adversely affect the operation of the heat pump and may also endanger life and property. The manufacturer disclaims any responsibility for such loss or injury resulting from the use of such unauthorized components, accessories or devices.

2.1 CHECKING PRODUCT RECEIVED

Upon receiving unit, inspect it for any shipping damage. Claims for damage, either apparent or concealed, should be filed immediately with the shipping company. Check heat pump model number, electrical characteristics and accessories to determine if they are correct. Check system components (evaporator coil, condensing unit, evaporator blower, etc.) to make sure they are properly matched. The information contained in this manual has been prepared to assist in the proper installation, operation and maintenance of the heat pump system. Improper installation, or installation not made in accordance with these instructions, can result in unsatisfactory operation and/or dangerous conditions, and can cause the related warranty not to apply.

Read this manual and any instructions packaged with separate equipment required to make up the system prior to installation. Retain this manual for future reference.

To achieve optimum efficiency and capacity, the indoor cooling coils listed in the heat pump specification sheet should be used.

2.2 APPLICATIONS

Before installing any heat pump equipment, a duct analysis of the structure and a heat gain calculation must be made. A heat gain calculation begins by measuring all external surfaces and openings that gain heat from the surrounding air and quantifying that heat gain. A heat gain calculation also calculates the extra heat load caused by sunlight and by humidity removal.


There are several factors that the installers must consider:

- Outdoor unit location
- System refrigerant charge
- Indoor unit blower speed
- System air balancing
- Proper equipment evacuation
- Indoor unit airflow
- Supply and return air duct design and sizing
- Diffuser and return air grille location and sizing

MATCH ALL COMPONENTS:

- OUTDOOR UNIT
- INDOOR COIL/METERING DEVICE
- INDOOR AIR HANDLER/FURNACE
- REFRIGERANT LINES

2.3 DIMENSIONS (SEE FIGURE 1)



2.4 ELECTRICAL & PHYSICAL DATA (SEE TABLE 1)

TABLE 1
ELECTRICAL AND PHYSICAL DATA

Model Number	Electrical Data							Physical Data					
	Phase Frequency (Hz) voltage (volts)	Compressor		Fan Motor Full Load Amperes (FLA)	Minimum Circuit Ampacity Amperes	Fuse or HACR Circuit Breaker		Outdoor Coil			Refrig.* Per Circuit Oz. [g]	Weight	
		Rated Load Amperes (RLA)	Locked Rotor Amperes (LRA)			Minimum Amperes	Maximum Amperes	Face Area Sq. Ft. [m ²]	No. Rows	CFM [L/s]		Net Lbs. [kg]	Shipping Lbs. [kg]
18	1-60-208/230	9/9	41	0.6	12/12	15/15	20/20	11.06 [1.03]	1	1700 [802]	81 [2296]	142 [64.4]	150 [68]
24	1-60-208/230	14.1/14.1	54	0.8	19/19	25/25	30/30	13.72 [1.27]	1	2370 [1118]	99 [2807]	180 [81.6]	190 [86.2]
30	1-60-208/230	14.6/14.6	67	0.8	20/20	25/25	30/30	16.39 [1.52]	1	2800 [1321]	115 [3260]	210 [95.3]	222 [100.7]
36	1-60-208/230	18/18	83	1.2	24/24	30/30	40/40	21.85 [2.03]	1	3575 [1687]	134 [3799]	224 [101.6]	236 [107]
42	1-60-208/230	19.2/19.2	105	1.2	26/26	35/35	40/40	21.85 [2.03]	1	3575 [1687]	150 [4252]	214 [97.1]	226 [102.5]
48	1-60-208/230	26.1/26.1	137	1.2	34/34	45/45	50/50	21.85 [2.03]	1	3575 [1687]	154 [4366]	220 [99.8]	232 [105.2]
60	1-60-208/230	25.3/25.3	150	1.2	33/33	40/40	50/50	21.85 [2.03]	2	3365 [1588]	256 [7258]	283 [128.4]	295 [133.8]

*note: units shipped with nitrogen holding charge. refrigerant quantity shown is for 15 ft. of standard line set.

3.0 LOCATING UNIT

3.1 CORROSIVE ENVIRONMENT

The metal parts of this unit may be subject to rust or deterioration if exposed to a corrosive environment. This oxidation could shorten the equipment's useful life. Corrosive elements include, but are not limited to, salt spray, fog or mist in seacoast areas, sulphur or chlorine from lawn watering systems, and various chemical contaminants from industries such as paper mills and petroleum refineries.

If the unit is to be installed in an area where contaminants are likely to be a problem, special attention should be given to the equipment location and exposure.

- Avoid having lawn sprinkler heads spray directly on the unit cabinet.
- In coastal areas, locate the unit on the side of the building away from the waterfront.
- Shielding provided by a fence or shrubs may give some protection, but cannot violate minimum airflow and service access clearances.
- Elevating the unit off its slab or base enough to allow air circulation will help avoid holding water against the basepan.

Regular maintenance will reduce the build-up of contaminants and help to protect the unit's finish.

WARNING

Disconnect all power to unit before starting maintenance. Failure to do so can cause electrical shock resulting in severe personal injury or death.

- Frequent washing of the cabinet, fan blade and coil with fresh water will remove most of the salt or other contaminants that build up on the unit.
- Regular cleaning and waxing of the cabinet with an automobile polish will provide some protection.
- A liquid cleaner may be used several times a year to remove matter that will not wash off with water.

Several different types of protective coil coatings are offered in some areas. These coatings may provide some benefit, but the effectiveness of such coating materials cannot be verified by the equipment manufacturer.

3.2 HEAT PUMP LOCATION

consult local and national building codes and ordinances for special installation requirements. Following location information will provide longer life and simplified servicing of the outdoor heat pump.

NOTE: These units must be installed outdoors. No ductwork can be attached, or other modifications made, to the discharge grille. Modifications will affect performance or operation.

3.3 OPERATIONAL ISSUES

- **IMPORTANT:** Locate the unit in a manner that will not prevent, impair or compromise the performance of other equipment horizontally installed in proximity to the unit. Maintain all required minimum distances to gas and electric meters, dryer vents, exhaust and inlet openings. In the absence of national codes, or manufacturers' recommendations, local code recommendations and requirements will take precedence.
- Refrigerant piping and wiring should be properly sized and kept as short as possible to avoid capacity losses and increased operating costs.
- Locate the unit where water run off will not create a problem with the equipment. Position the unit away from the drip edge of the roof whenever possible. Units are weatherized, but can be affected by the following:
 - o Water pouring into the unit from the junction of rooflines, without protective guttering. Large volumes of water entering the heat pump while in operation can impact fan blade or motor life, and coil damage may occur to a heat pump if moisture cannot drain from the unit under freezing conditions.
 - o Freezing moisture, or sleeting conditions, can cause the cabinet to ice-over prematurely and prevent heat pump operation, requiring backup heat, which generally results in less economical operation.
- Closely follow clearance recommendations (See Figure 1).
 - o 24" to the service panel access
 - o 60" above heat pump fan discharge (unit top) to prevent recirculation
 - o 6" to heat pump coil grille air inlets (per heat pump).

3.4 FOR UNITS WITH SPACE LIMITATIONS

In the event that a space limitation exists, we will permit the following clearances:

Single Unit Applications: Clearances below 6 inches will reduce unit capacity and efficiency. Do not reduce the 60-inch discharge, or the 24-inch service clearances.


Multiple Unit Applications: When multiple heat pump grille sides are aligned, a 6-inch per unit clearance is recommended, for a total of 12" between two units. Two combined clearances below 12 inches will reduce capacity and efficiency. Do not reduce the 60-inch discharge, or 24-inch service, clearances.

- Do not obstruct the bottom drain opening in the heat pump base pan. It is essential to provide defrost condensate drainage to prevent possible refreezing of the condensation. Provide a base pad for mounting the unit, which is slightly pitched away from the structure. Route condensate off the base pad to an area which will not become slippery and result in personal injury.
- Where snowfall is anticipated, the heat pump must be elevated above the base pad to prevent ice buildup that may crush the tubing of the heat pump coil or cause fin damage. Heat pump units should be mounted above the average expected accumulated snowfall for the area.

3.5 CUSTOMER SATISFACTION ISSUES

- The heat pump should be located away from the living, sleeping and recreational spaces of the owner and those spaces on adjoining property.
- To prevent noise transmission, the mounting pad for the outdoor unit should not be connected to the structure, and should be located sufficient distance above grade to prevent ground water from entering the unit.

FIGURE 2
RECOMMENDED ELEVATED INSTALLATION



3.6 UNIT MOUNTING

if elevating the heat pump, either on a flat roof or on a slab, observe the following guidelines.

- the base pan provided elevates the heat pump 2" above the base pad.
- if elevating a unit on a flat roof, use 4" x 4" (or equivalent) stringers positioned to distribute unit weight evenly and prevent noise and vibration (see figure 2).

NOTE: Do not block drain openings shown in figure 1.

- if unit must be elevated because of anticipated snow fall, secure unit and elevating stand such that unit and/or stand will not tip over or fall off. Keep in mind that someone may try to climb on unit.

3.7 FACTORY-PREFERRED TIE-DOWN METHOD FOR OUTDOOR UNITS:

IMPORTANT: the manufacturer's approved/recommended method is a guide to securing equipment for wind and seismic loads. other methods might provide the same result, but the manufacturer's method is the only one endorsed by the manufacturer for securing equipment where wind or earthquake damage can occur. Additional information is available in the Product Technical Support section of the manufacturer's website heemote.net and can be found as a listing under each outdoor model. if you do not have access to this site, your Distributor can offer assistance.

4.0 REFRIGERANT CONNECTIONS

All units are factory charged with a nitrogen holding charge. All models are supplied with service valves. Keep tube ends sealed until connection is to be made to prevent system contamination.

5.0 REPLACEMENT UNITS

To prevent failure of a new heat pump unit, the existing tubing system must be correctly sized and cleaned or replaced. Care must be exercised that the expansion device is not plugged. For new and replacement units, a liquid line filter drier should be installed and refrigerant tubing should be properly sized. Test the oil for acid. If positive, a liquid line filter drier is mandatory.

6.0 INDOOR COIL

Refer to Indoor Coil Manufacturer's Instructions. Important: The manufacturer is not responsible for the performance and operation of a mismatched system, or for a match listed with another manufacturer's coil.

6.1 LOCATION

Do not install the indoor coil in the return duct system of a gas or oil furnace. Provide a service inlet to the coil for inspection and cleaning. Keep the coil pitched toward the drain connection.

CAUTION

When coil is installed over a finished ceiling and/or living area, it is recommended that a secondary sheet metal condensate pan be constructed and installed under entire unit. Failure to do so can result in property damage.

7.0 INTERCONNECTING TUBING

7.1 VAPOR AND LIQUID LINES

Keep all lines sealed until connection is made.

Refer to Line Size information in Tables 2 and 4 for correct size and multipliers to be used to determine capacity for various vapor line diameters and lengths of run. The losses due to the lines being exposed to outdoor conditions are not included.

IMPORTANT: Units are shipped with a nitrogen holding charge. Open service valves to vent the nitrogen before connecting the suction and liquid lines to the service valves. Lines must be connected immediately after nitrogen is vented to prevent contamination of system. Do not leave the system open to the atmosphere more than 15 minutes.

The nameplate refrigeration charge in the outdoor unit is zero. The charging chart for the outdoor unit is based on the unit and 15 feet of standard size interconnecting liquid and vapor lines. For different lengths, adjust the charge as indicated below.

1/4" ± .3 oz. per foot

5/16" ± .4 oz. per foot

3/8" ± .6 oz. per foot

1/2" ± 1.2 oz. per foot

7.2 MAXIMUM LENGTH OF LINES

The maximum length of interconnecting line is 150 feet. Always use the shortest length possible with a minimum number of bends. Additional compressor oil is not required for any length up to 150 feet.

NOTE: excessively long refrigerant lines cause loss of equipment capacity.

7.3 OUTDOOR UNIT INSTALLED ABOVE INDOOR COIL

Keep the vertical separation between coils to a minimum. However, the vertical distance can be as great as 120 feet with the condensing unit above the indoor coil. Use the following guidelines when installing the unit:

1. Do not exceed 120 feet maximum vertical separation.
2. Do not change the flow check piston sizes if the vertical separation does not exceed the values in table 3.
3. expansion valve coil:
 - a. the vertical separation can be greater than the table value, but no more than 120 feet.
 - b. no changes are required for expansion valve coils.
4. Always use the smallest liquid line size permitted to minimize the system charge.
5. table 3 may be used for sizing horizontal runs.

7.4 OUTDOOR UNIT BELOW INDOOR COIL

Keep the vertical separation to a minimum. Use the following guidelines when installing the unit:

1. Do not exceed the vertical separations as indicated on table 3.
2. Always use the smallest liquid line size permitted to minimize system charge.
3. no changes are required for either flow check piston coils or expansion coils.
4. table 4 may be used for sizing horizontal runs.

7.5 TUBING INSTALLATION

Observe the following when installing correctly sized type "L" refrigerant tubing between the condensing unit and evaporator coil:

- if a portion of the liquid line passes through a hot area where liquid refrigerant can be heated to form vapor, insulating the liquid line is required.
- use clean, dehydrated, sealed refrigeration grade tubing.
- Always keep tubing sealed until tubing is in place and connections are to be made.
- Blow out the liquid and vapor lines with dry nitrogen before connecting to the outdoor unit and indoor coil. Any debris in the line set will end up plugging the expansion device.
- As an added precaution it is recommended that a high quality, bi-directional filter drier is installed in the liquid line.
- Do not allow the vapor line and liquid line to be in contact with each other. This causes an undesirable heat transfer resulting in capacity loss and increased power consumption. The vapor line must be insulated.
- if tubing has been cut, make sure ends are deburred while holding in a position to prevent chips from falling into tubing. Burrs such as those caused by tubing cutters can affect performance dramatically, particularly on small liquid line sizes.
- for best operation, keep tubing run as short as possible with a minimum number of elbows or bends.
- Locations where the tubing will be exposed to mechanical damage should be avoided. if it is necessary to use such locations, the copper tubing should be housed to prevent damage.
- if tubing is to be run underground, it must be run in a sealed watertight chase.
- use care in routing tubing and do not kink or twist. Use a tubing bender on the vapor line to prevent kinking.
- route the tubing using temporary hangers, then straighten the tubing and install permanent hangers. Line must be adequately supported.

- the vapor line must be insulated to prevent dripping (sweating) and prevent performance losses. Armaflex and Rubatex are satisfactory insulations for this purpose. Use 1/2" minimum insulation thickness, additional insulation may be required for long runs.
- Check Table 2 for the correct vapor line size. Check Table 3 for the correct liquid line size.

7.6 TUBING CONNECTIONS

Indoor coils have only a holding charge of dry nitrogen. Keep all tube ends sealed until connections are to be made.

- Use type "L" copper refrigeration tubing. Braze the connections with accepted industry practices.
- Be certain both refrigerant shutoff valves at the outdoor unit are closed.
- Clean the inside of the fittings before brazing.
- Remove the cap and Schrader core from service port to protect seals from heat damage.
- Use an appropriate heatsink material around the copper stub and the service valves before applying heat.
- **IMPORTANT:** Do not braze any fitting with the temperature sensing bulb attached.
- Braze the tubing between the outdoor unit and indoor coil. Flow dry nitrogen into a service port and through the tubing while brazing.
- The service valves are not backseating valves. To open the valves, remove the valve cap with an adjustable wrench. Insert a 3/16" or 5/16" hex wrench into the stem. Back out counterclockwise.
- Replace the valve cap finger tight then tighten an additional 1/2 hex flat for a metal-to-metal seal.

7.7 LEAK TESTING

- Pressurize line set and coil through service fittings with dry nitrogen to 150 pSiG maximum. Leak test all joints using liquid detergent. If a leak is found, relieve pressure and repair.

TABLE 2
SUCTION LINE LENGTH AND CAPACITY MULTIPLIER

Unit Size	1 1/2 Ton	2 Ton	2 1/2 Ton	3 Ton	3 1/2 Ton	4 Ton	5 Ton
Suction Line Connection Size	3/4" I.D.	3/4" I.D.	3/4" I.D.	7/8" I.D.	7/8" I.D.	7/8" I.D.	7/8" I.D.
Suction Line Run - Feet	5/8 3/4* ---	5/8 3/4* 7/8	5/8 3/4* 7/8	3/4 7/8* ---	3/4 7/8* 1 1/8	7/8 1 1/8* ---	7/8 1 1/8* ---
25'	Optional	0.99	0.99	0.98	0.99	0.99	0.99
	Standard	1.00	1.00	1.00	1.00	1.00	1.00
 Optional	---	1.00	1.00	---	1.00	---
50'	Optional	0.97	0.96	0.96	0.98	0.97	0.97
	Standard	0.99	0.99	0.98	0.99	0.98	0.99
 Optional	---	0.99	0.99	---	1.00	---
100'	Optional	0.94	0.92	0.94	0.95	0.93	0.95
	Standard	0.96	0.96	0.96	0.96	0.96	0.98
 Optional	---	0.97	0.97	---	0.98	---
150'	Optional	0.90	0.89	0.92	0.93	0.92	0.93
	Standard	0.93	0.93	0.93	0.94	0.94	0.96
 Optional	---	0.95	0.95	---	0.96	---

NOTES:

*Standard line size

n/A: Using suction line larger than shown in chart will result in poor oil return and is not recommended.

TABLE 3
LIQUID LINE SIZE

System Capacity	Liquid Line Connection Size (Inch I.D.)	Line Size (Inch OD)	Liquid Line Size Outdoor unit above or below indoor coil (Heat Pumps Only)					
			Total Equivalent Length - Feet					
			25	50	75	100	125	150
			Maximum Vertical Separation - Feet					
1 1/2 Ton	3/8"	1/4	21	8	N/A	N/A	N/A	N/A
		5/16	25	27	24	21	17	14
		3/8*	25	40	39	38	37	35
2 Ton	3/8"	1/4	16	N/A	N/A	N/A	N/A	N/A
		5/16	25	26	21	15	10	5
		3/8*	25	38	36	35	33	31
2 1/2 Ton	3/8"	1/4	0	N/A	N/A	N/A	N/A	N/A
		5/16	25	17	8	0	N/A	N/A
		3/8*	25	37	34	31	29	26
3 Ton	3/8"	5/16	25	15	4	N/A	N/A	N/A
		3/8*	25	30	26	23	19	16
3 1/2 Ton	3/8"	5/16	25	17	2	N/A	N/A	N/A
		3/8*	25	37	32	28	23	18
4 Ton	3/8"	3/8*	25	33	27	21	15	9
		1/2	25	43	42	40	39	38
5 Ton	3/8"	3/8*	25	25	17	8	0	N/A
		1/2	25	39	37	36	34	32

NOTES:

* Standard line size.

n/A = Application not recommended

8.0 DEMAND DEFROST CONTROL

The demand defrost control is a printed circuit board assembly consisting of solid state control devices with electro-mechanical outputs. The demand defrost control monitors the outdoor ambient temperature, outdoor coil temperature, and the compressor run-time to determine when a defrost cycle is required.

8.1 DEFROST INITIATION

A defrost will be initiated when the three conditions below are satisfied:


- 1) The outdoor coil temperature is below 35°F .
- 2) The compressor has operated for at least 34 minutes with the outdoor coil temperature below 35°F .
- 3) The measured difference between the ambient temperature and the outdoor coil temperature is greater than the calculated delta t .

Additionally, a defrost will be initiated if six hours of accumulated compressor run-time has elapsed without a defrost with the outdoor coil temperature below 35°F .

8.2 DEFROST TERMINATION (See Figure 4)

Once a defrost is initiated, the defrost will continue until fourteen minutes has elapsed or the coil temperature has reached the terminate temperature. The terminate temperature is factory set at 70°F , although the temperature can be changed to 50°F , 60°F , 70°F or 80°F by relocating a jumper on the board.

FIGURE 4
DEFROST TERMINATION SETTINGS



8.3 TEMPERATURE SENSORS

The coil sensor is clipped to the top tube on the outdoor coil at the point feed by the distribution tubes from the expansion device (TEV) (short 3/8" dia. tube). The air sensor is located on the defrost control board.

If the ambient sensor fails the defrost control will initiate a defrost every 34 minutes with the coil temperature below 35°F .

If the coil sensor fails the defrost control will not initiate a defrost.

8.4 TEST MODE

The test mode is initiated by shorting the test pins. In this mode of operation, the enable temperature is ignored and all timers are sped up by a factor of 240. To initiate a manual defrost, short the test pins. Remove the short when the system switches to defrost mode. The defrost will terminate on time (14 minutes) or when the termination temperature has been achieved. Short test pins again to terminate the defrost immediately.

8.5 DEMAND DEFROST OPERATION

It is important that such systems be off for a minimum of 5 minutes before restarting to allow equalization of pressures. The thermostat should not be moved to cycle unit without waiting five minutes. To do so may cause the compressor to stop on an automatic opening overload device or blow a fuse. Poor electrical service can cause nuisance tripping on overloads or blow fuses. For PSC type operation, the refrigerant metering must be done with cap tubes, flow check, or bleed type expansion valve because of low starting torque.

IMPORTANT: The compressor has an internal overload protector. Under some conditions, it can take up to 2 hours for this overload to reset. Make sure overload has had time to reset before condemning the compressor.

8.6 TROUBLE SHOOTING DEMAND DEFROST

Set the indoor thermostat select switch to heat and thermostat lever to a call for heat.

Jumper the "test pins" to put the unit into defrost. If the unit goes into defrost and comes back out of defrost, the indication is that the control is working properly.

If the unit did not go into defrost using the test pins, check to ensure that 24v is being supplied to the control board. If 24v is present then replace the control.

The defrost control is equipped with a red LED that will flash fault codes if a fault has been detected. The codes are as follows:

LED	Trouble-shooting codes:
Steady "on"	Normal operation
1 flash	Defrost initiated
2 flashes	Outdoor coil temperature sensor fault
3 flashes	Outdoor Ambient temperature sensor fault

9.0 EVACUATION PROCEDURE

Evacuation is the most important part of the entire service procedure. The life and efficiency of the equipment is dependent upon the thoroughness exercised by the serviceman when evacuating air and moisture from the line set and indoor coil.

Air in the system causes high condensing temperatures and pressure, resulting in increased power input and non-verifiable performance.

Moisture chemically reacts with the refrigerant and oil to form corrosive hydrofluoric and hydrochloric acids. These attack motor windings and parts, causing breakdown.

After the system has been leak checked and proven sealed, connect the vacuum pump and evacuate system to 500 microns. The vacuum pump must be connected to both the high and low sides of the system through adequate connections. Use the largest size connections available since restrictive service connections may lead to false readings because of pressure drop through the fittings.

IMPORTANT: Compressors (especially scroll type) should never be used to evacuate the air conditioning system because internal electrical arcing may result in a damaged or failed compressor.

NOTE: Unit is shipped with a nitrogen holding charge. Service valves must be opened prior to evacuation to allow condensing unit to be evacuated along with the line set and indoor coil.

10.0 START UP AND PERFORMANCE

After system evacuation, charge system with the amount shown in table 1 on page 6, before the system is started for the first time. The charge must then be checked to the charge table attached to the service panel and adjusted, if required. Allow a minimum of 5 minutes running. Before analyzing charge, see the instructions on the unit service panel rating plate for marking the total charge.

11.0 CHECKING AIRFLOW

The air distribution system has the greatest effect on airflow. The duct system is totally controlled by the contractor. For this reason, the contractor should use only industry-recognized procedures.

Heat pump systems require a specified airflow. Each ton of cooling requires between 350 and 450 cubic feet of air per minute (cfm), or 400 cfm nominally.

Duct design and construction should be carefully done. System performance can be lowered dramatically through bad planning or workmanship.

Air supply diffusers must be selected and located carefully. They must be sized and positioned to deliver treated air along the perimeter of the space. If they are too small for their intended airflow, they become noisy. If they are not located properly, they cause drafts. Return air grilles must be properly sized to carry air back to the blower. If they are too small, they also cause noise.

The installers should balance the air distribution system to ensure proper quiet airflow to all rooms in the home. This ensures a comfortable living space.

An air velocity meter or airflow hood can give a reading of the system cfm's.

12.0 CHECKING REFRIGERANT CHARGE

Charge for all systems should be checked against the charging chart inside the access panel cover.

IMPORTANT: Do not operate the compressor without charge in system.

Addition of R-22 will raise pressures (vapor, liquid and discharge).

If adding R-22 raises both vapor pressure and temperature, the unit is overcharged.

IMPORTANT: Use industry-approved charging methods to ensure proper system charge.

12.1 CHARGING BY LIQUID PRESSURE

The liquid pressure method is used for charging systems in the cooling and heating mode. The service port on the liquid (small valve) and suction (large valve) is used for this purpose.

Verify that the outdoor unit is running and the indoor air mover is delivering the maximum airflow for this system size. Read and record the outdoor ambient temperature. Read and record the liquid and suction pressures at the ports on the liquid and suction valves.

If refrigerant lines are sized using the nameplate charge, the correct liquid pressure is found at the intersection of the suction pressure and the outdoor ambient.

1. Remove refrigerant charge if the liquid pressure is above the chart value.
2. Add refrigerant charge if the liquid pressure is below the chart value.

12.2 CHARGING BY WEIGHT (UNITS SHIPPED WITH NITROGEN HOLDING CHARGE ONLY)

evacuate the entire system. Be sure to open both service valves prior to evacuation. Add the charge shown in table 1 of these instructions. Note that charge value includes charge required for 15 ft. of standard size interconnecting liquid line. Calculate actual charge required with installed liquid line size and length using:

1/4" o.D. = .3 oz./ft.

5/16" o.D. = .4 oz./ft.

3/8" o.D. = .6 oz./ft.

1/2" o.D. = 1.2 oz./ft.

With an accurate scale (+/- 1 oz.) or volumetric charging device, adjust charge difference between that shown on the unit data plate and that calculated for the new system installation. If the entire system has been evacuated, add the total calculated charge.

12.3 FINAL LEAK TESTING

After the unit has been properly evacuated and charged, a halogen leak detector should be used to detect leaks in the system. All piping within the condensing unit, evaporator, and interconnecting tubing should be checked for leaks. If a leak is detected, the refrigerant should be recovered before repairing the leak. The Clean Air Act prohibits releasing refrigerant into the atmosphere.

13.0 ELECTRICAL WIRING

WARNING

Turn off electric power at the fuse box or service panel before making any electrical connections.

Also, the ground connection must be completed before making line voltage connections. Failure to do so can result in electrical shock, severe personal injury or death.

Field wiring must comply with the national electric code (N.E.C. in Canada) and any applicable local code.

13.1 POWER WIRING

It is important that proper electrical power from a commercial utility is available at the heat pump contactor. Voltage ranges for operation are shown in table 6.

Install a branch circuit disconnect within sight of the unit and of adequate size to handle the starting current (see table 1).

Power wiring must be run in a rain-tight conduit. Conduit must be run through the connector panel below the access cover (see figure 1) and attached to the bottom of the control box.

Connect power wiring to contactor located in outdoor heat pump electrical box. (See wiring diagram attached to unit access panel.)

Check all electrical connections, including factory wiring within the unit and make sure all connections are tight.

Do not connect aluminum field wire to the contactor terminals.

13.2 GROUNDING

A grounding lug is provided near the contactor for a ground wire.

WARNING

The unit must be permanently grounded. Failure to do so can cause electrical shock resulting in severe personal injury or death.

TABLE 4
vOLTAGE RANGES (60 Hz)

nameplate voltage	operating voltage range at copeland maximum Load Design conditions for compressors
208/230 (1 phase)	197 - 253


13.3 CONTROL WIRING

(See Figure 5)

if the low voltage control wiring is run in conduit with the power supply, class i insulation is required. class ii insulation is required if run separate. Low voltage wiring may be run through the insulated bushing provided in the 7/8 hole in the base panel, up to and attached to the pigtails from the bottom of the control box. conduit can be run to the base panel if desired by removing the insulated bushing.

A thermostat and a 24 volt, 40 vA minimum transformer are required for the control circuit of the condensing unit. the furnace or the air handler transformer may be used if sufficient. See the wiring diagram for reference. use table 5 to size the 24 volt control wiring.

FIGURE 5
CONTROL WIRING FOR AIR HANDLER



NOTES:

1. Jumper "e" to "W2" on thermostat to transfer control of supplemental heat to 1st stage when the emergency heat switch is on.
2. this wire turns on electric heat strip during defrost, omit for most economical operation.

WIRE COLOR CODE

BK = BLAcK
BL = BLue
Br = Br oWn
Gr = Gr een
pr = pur pLe
rD = r eD
WH = WHit e
yL = yeLLoW

*Not present on all air-handler models.

TABLE 5
FIELD WIRE SIZE FOR 24 vOLT THERMOSTAT CIRCUITS

Thermostat Load - Amps	SOLID COPPER WIRE - AWG.					
	50	100	150	200	250	300
3.0	16	14	12	10	10	10
2.5	16	14	12	12	10	10
2.0	18	16	14	12	12	10

(1) Wire length equals twice the run distance.

note: Do not use control wiring smaller than no. 18 AWG between thermostat and outdoor unit.

14.0 FIELD INSTALLED ACCESSORIES

14.1 COMPRESSOR CRANKCASE HEATER (CCH)

While scroll compressors usually do not require crankcase heaters, there are instances when a heater should be added. Refrigerant migration during the off cycle can result in a noisy start up. Add a crankcase heater to minimize refrigeration migration, and to help eliminate any start up noise or bearing “wash out.”

TABLE 6
MAXIMUM SYSTEM CHARGE VALUES

Model Size*	Compressor Manufacturer	Compressor Model Number	Charge Limit Without Crankcase Heat*
42	Danfoss	Hr m038u 1Lp6	8 lbs.
48	Danfoss	Hr m045u 1Lp6	8 lbs.

*All other models come with the crankcase heater factory-installed.

NOTE: The installation of a crankcase heater is recommended if the system charge exceeds the values in table 6.

All heaters are located on the lower half of the compressor shell. Its purpose is to drive refrigerant from the compressor shell during long off cycles, thus preventing damage to the compressor during start-up.

At initial start-up or after extended shutdown periods, make sure the heater is energized for at least 12 hours before the compressor is started. (Disconnect switch on and wall thermostat off.)

14.2 LOW AMBIENT CONTROL (LAC) – COOLING MODE ONLY

This component senses compressor head pressure and shuts the heat pump fan off when the head pressure drops to approximately 175 pSiG. This allows the unit to build a sufficient head pressure at lower ambient in order to maintain system balance and obtain improved capacity. Low ambient control should be used on all equipment operated below 65°F ambient.

14.3 HIGH PRESSURE CONTROL (HPC)

This control keeps the compressor from operating in pressure ranges which can cause damage to the compressor. This control is in the low voltage control circuit.

High pressure control (Hpc) is a manual reset which opens near 450 pSiG. Do not reset arbitrarily without first determining what caused it to trip.

15.0 SERVICE

15.1 SINGLE-POLE COMPRESSOR CONTACTOR (CC)

CAUTION


Single-pole contactors are used on all standard single-phase units up through 5 tons. Caution must be exercised when servicing as only one leg of the power supply is broken with the contactor.

16.0 TROUBLE SHOOTING


in diagnosing common faults in the heat pump system, develop a logical thought pattern as used by experienced technicians. The charts which follow are not intended to be an answer to all problems but only to guide the technician's thinking. Through a series of yes and no answers, follow the logical path to a likely conclusion.

A novice technician should use these charts like a road map. Remember that the chart should clarify a logical path to the problem's solution.


16.1 ELECTRICAL CHECKS FLOW CHART



16.2 COOLING MECHANICAL CHECKS FLOW CHART



16.3 HEATING MECHANICAL CHECKS FLOW CHART



16.4 DEFROST MECHANICAL CHECKS FLOW CHART




TABLE 7
TEMPERATURE PRESSURE CHART

TEMP (Deg. F)	R-22 PSIG
-150	*29.4
-140	*29.1
-130	*28.5
-120	*27.7
-110	*26.6
-100	*25.1
-90	*23.0
-80	*20.2
-70	16.6
-60	*11.9
-50	*6.1
-40	0.6
-35	2.6
-30	4.9
-25	7.5
-20	10.2
-15	13.2
-10	16.5
-5	20.1
0	24.0
5	28.3
10	32.8
15	37.8
20	43.1
25	48.8
30	54.9
35	61.5
40	68.5
45	76.1
50	84.1
55	92.6
60	101.6
65	111.3
70	121.4
75	132.2
80	143.7
85	155.7
90	168.4
95	181.8
100	196.0
105	210.8
110	226.4
115	242.8
120	260.0
125	278.1
130	297.0
135	316.7
140	337.4
145	359.1
150	381.7

16.5 SUBCOOLING CALCULATION

1. measure the liquid pressure at the liquid line service valve.
2. convert the liquid line pressure to saturated temperature. See table 9.
3. measure the liquid line temperature at the liquid line service valve.
4. compare the liquid line temperature to the saturated temperature.
5. the difference between saturated temperature and liquid line temperature is the subcooling. Subcooling normal range 9° to 12°.

NOTE: the subcooling charging method should only be used in the cooling mode as the heating subcooling design level varies widely from one unit to the next while the cooling subcooling design level is fairly consistent at 8-12 degrees.

TABLE 8
HEAT PUMP SYSTEM TROUBLESHOOTING TIPS

HEAT PUMP SYSTEM TROUBLESHOOTING TIPS					
SYSTEM PROBLEM	INDICATORS				
	DISCHARGE PRESSURE	SUCTION PRESSURE	SUPERHEAT	SUBCOOLING	COMPRESSOR AMPS
overcharge	High	High	Low	High	High
undercharge	Low	Low	High	Low	Low
Liquid restriction (Drier)	Low	Low	High	High	Low
Low evaporator Airflow	Low	Low	Low	Low	Low
Dirty Heat pump	High	High	Low	Low	High
Low outside Ambient temperature	Low	Low	High	High	Low
inefficient compressor	Low	High	High	High	Low
test feeler Bulb charge Lost	Low	Low	High	High	Low
poorly insulated Sensing Bulb	High	High	Low	Low	High

16.6 GENERAL TROUBLE SHOOTING CHART

▲ WARNING

Disconnect all power to unit before servicing. Contactor may break only one side. Failure to shut off power can cause electrical shock resulting in personal injury or death.

SYMPTOM	POSSIBLE CAUSE	REMEDY
unit will not run	<ul style="list-style-type: none"> power off or loose electrical connection thermostat out of calibration-set too high Defective contactor Blown fuses / tripped breaker transformer defective High pressure control open (if provided) 	<ul style="list-style-type: none"> check for correct voltage at contactor in condensing unit reset check for 24 volts at contactor coil - replace if contacts are open replace fuses / reset breaker check wiring-replace transformer reset-also see high head pressure remedy-the high pressure control opens at 450 pSiG
indoor fan runs, compressor doesn't	<ul style="list-style-type: none"> run or start capacitor defective Start relay defective Loose connection compressor stuck, grounded or open motor winding, open internal overload. Low voltage condition 	<ul style="list-style-type: none"> replace replace check for correct voltage at compressor - check & tighten all connections Wait at least 2 hours for overload to reset. if still open, replace the compressor. Add start kit components
insufficient cooling	<ul style="list-style-type: none"> improperly sized unit improper indoor airflow incorrect refrigerant charge Air, non-condensibles or moisture in system 	<ul style="list-style-type: none"> recalculate load check - should be approximately 400 cfm per ton. charge per procedure attached to unit service panel recover refrigerant, evacuate & recharge, add filter drier
compressor short cycles	<ul style="list-style-type: none"> incorrect voltage Defective overload protector refrigerant undercharge 	<ul style="list-style-type: none"> At compressor terminals, voltage must be $\pm 10\%$ of nameplate marking when unit is operating. replace - check for correct voltage Add refrigerant
registers sweat	<ul style="list-style-type: none"> Low indoor airflow 	<ul style="list-style-type: none"> increase speed of blower or reduce restriction - replace air filter
High head-low vapor pressures	<ul style="list-style-type: none"> restriction in liquid line, expansion device or filter drier float check piston size too small incorrect capillary tubes 	<ul style="list-style-type: none"> remove or replace defective component change to correct size piston change coil assembly
High head-high or normal vapor pressure - cooling mode	<ul style="list-style-type: none"> Dirty outdoor coil refrigerant overcharge indoor fan not running Air or non-condensibles in system 	<ul style="list-style-type: none"> clean coil correct system charge repair or replace recover refrigerant, evacuate & recharge
Low head-high vapor pressures	<ul style="list-style-type: none"> float check piston size too large Defective compressor valves incorrect capillary tubes 	<ul style="list-style-type: none"> change to correct size piston replace compressor replace coil assembly
Low vapor - cool compressor - iced indoor coil	<ul style="list-style-type: none"> Low indoor airflow operating below 65°F outdoors moisture in system 	<ul style="list-style-type: none"> increase speed of blower or reduce restriction - replace air filter Add Low Ambient Kit recover refrigerant - evacuate & recharge - add filter drier
High vapor pressure	<ul style="list-style-type: none"> excessive load Defective compressor 	<ul style="list-style-type: none"> recheck load calculation replace
fluctuating head & vapor pressures	<ul style="list-style-type: none"> tevi hunting Air or non-condensibles in system 	<ul style="list-style-type: none"> check tevi bulb clamp - check air distribution on coil - replace tevi recover refrigerant, evacuate & recharge
Gurgle or pulsing noise at expansion device or liquid line	<ul style="list-style-type: none"> Air or non-condensibles in system 	<ul style="list-style-type: none"> recover refrigerant, evacuate & recharge

16.7 SERVICE ANALYZER CHART

COMPRESSOR OVERHEATING		
SYMPTOMS	POSSIBLE CAUSE	CHECK/REMEDIES
High superheat	Low charge	check system charge
	faulty metering device	restricted cap tube, t e v (t Xv)
		power element superheat adjustment
		foreign matter stopping flow
	High internal load	Hot air (attic) entering return
		Heat source on; mis-wired or faulty control
	restriction in liquid line	Drier plugged
		Line kinked
	Low head pressure	Low charge
		operating in low ambient temperatures
Suction or liquid line subjected to high heat source	Hot attic	
	Hot water line	
Low voltage	Loose wire connections	check wiring
	Dirty or pitted compressor contactor contacts	replace contactor
	power company problem, transformer	Have problem corrected before diagnosis continues
	undersized wire feeding unit	correct and complete diagnosis
High voltage	power company problem	Have problem corrected
High head pressure	overcharge	check system charge
	Dirty heat pump coil	clean coil
	faulty or wrong size heat pump fan motor	replace fan motor
		replace fan blade
	faulty fan blade or wrong rotation	replace with correct rotation motor
		recirculation of air
	Additional Heat Source	check for dryer vent near unit
		check for recirculation from other equipment
non-condensibles	recover refrigerant, evacuate and recharge system	
equipment not matched	correct mis-match	
Short cycling of compressor	faulty pressure control	replace pressure control
	Loose wiring	check unit wiring
	thermostat	Located in supply air stream
		Differential setting too close
		customer misuse
	t e v	internal foreign matter
		power element failure
		valve too small
		Distributor tube/tubes restricted
	capillary tube	restricted with foreign matter
Kinked		
i.D. reduced from previous compressor failure		

SYMPTOMS	POSSIBLE CAUSE	CHECK OR REMEDIES
Short cycling of compressor (cont.)	Low charge	check system charge
	Low evaporator air flow	Dirty coil
		Dirty filter
		Duct too small or restricted
faulty run capacitor	faulty run capacitor	replace
	faulty internal overload	replace compressor
faulty compressor valves	fast equalization/ Low pressure difference	replace compressor and examine system to locate reason
<i>ELECTRICAL</i>		
SYMPTOMS	POSSIBLE CAUSE	CHECK OR REMEDIES
voltage present on load side of compressor contactor and compressor won't run	compressor start components	check start capacitor
		check potential relay
	run capacitor	check with ohmmeter
	internal overload	Allow time to reset
voltage present on line side of compressor contactor only	compressor windings	check for correct ohms
		thermostat
	compressor control circuit	High pressure switch
		Low pressure switch
		Ambient thermostat
no voltage on line side of compressor contactor	Blown fuses or tripped circuit breaker	check for short in wiring or unit
	improper wiring	re-check wiring diagram
improper voltage	High voltage	Wrong unit
		power supply problem
	Low voltage	Wrong unit
		power supply problem
		Wiring undersized
Single phasing (3 phase)	Loose connections	
<i>CONTAMINATION</i>		
SYMPTOMS	POSSIBLE CAUSE	CHECK OR REMEDIES
moisture	poor evacuation on installation or during service	in each case, the cure is the same. recover refrigerant. Add filter drier, evacuate and re-charge
High head pressure	non-condensibles air	
unusual head and suction readings	Wrong refrigerant	
foreign matter-copper filings	copper tubing cuttings	
copper oxide	Dirty copper piping	
Welding scale	nitrogen not used	
Soldering flux	Adding flux before seating copper part way	
excess soft solder	Wrong solder material	

LOSS OF LUBRICATION		
SYMPTOMS	POSSIBLE CAUSE	CHECK OR REMEDIES
compressor failures	Line tubing too long	Add oil to the recommended level
	Line tubing too large	reduce pipe size to improve oil return
Low suction pressure	Low charge	check system charge
	refrigerant leaks	repair and recharge
cold, noisy compressor - Slugging	Dilution of oil with refrigerant	observe piping guidelines
noisy compressor	migration	check crankcase heater
cold, sweating compressor	flooding	check system charge
Low Load	reduced air flow	Dirty filter
		Dirty coil
		Wrong duct size
		restricted duct
Short cycling of compressor	thermostat setting	Advise customer
	faulty pressure control	replace control
	Loose wiring	check all control wires
	thermostat	in supply air stream, out of calibration, customer misuse
FLOODED STARTS		
SYMPTOMS	POSSIBLE CAUSES	CHECK OR REMEDIES
Liquid in the compressor shell	faulty or missing crankcase heater	replace crankcase heater
too much liquid in system	incorrect piping	check piping guidelines
	overcharge	check and adjust charge
SLUGGING		
SYMPTOMS	POSSIBLE CAUSES	CHECK OR REMEDIES
on start up	incorrect piping	review pipe size guidelines
tevh hunting when running	oversized tevh	check tevh application
FLOODING		
SYMPTOMS	POSSIBLE CAUSES	CHECK OR REMEDIES
poor system control using a tevh	Loose sensing bulb	Secure the bulb and insulate
	Bulb in wrong location	relocate bulb
	Wrong size tevh	use correct replacement
	improper superheat setting	Adjust, if possible; replace, if not
poor system control using capillary tubes	overcharge	check system charge
	High head pressures	Dirty heat pump
		restricted air flow
recirculation of air		
evaporator air flow too low		Adjust air flow to 400 cfm/ton

THERMOSTATIC EXPANSION VALVES


SYMPTOMS	POSSIBLE CAUSE	CHECK OR REMEDIES	
High Superheat, Low Suction pressure	moisture freezing and blocking valve	recover charge, install filter-drier, evacuate system, recharge	
	Dirt or foreign material blocking valve	recover charge, install filter-drier, evacuate system, recharge	
	Low refrigerant charge	correct the charge	
	vapor bubbles in liquid line	remove restriction in liquid line	correct the refrigerant charge
		remove non-condensable gases	Size liquid line correctly
		Size liquid line correctly	
	misapplication of internally equalized valve	use correct t ev	
	plugged external equalizer line	remove external equalizer line restriction	
	undersized t ev	replace with correct valve	
	Loss of charge from power head sensing bulb	replace power head or complete t ev	
	charge migration from sensing bulb to power head (Warm power head with warm, wet cloth. Does valve operate correctly now?)	ensure t ev is warmer than sensing bulb	
improper superheat adjustment (only applicable to t ev with adjustable superheat settings)	Adjust superheat setting counter-clockwise		
v valve feeds too much refrigerant, with low superheat and higher than normal suction pressure	moisture causing valve to stick open.	recover refrigerant, replace filter-drier, evacuate system and then non-recharge	
	Dirt or foreign material causing valve to stick open	recover refrigerant, replace filter-drier, evacuate system and recharge	
	t ev seat leak (A gurgling or hissing sound is heard At t He t ev during the off cycle, if this is the cause.) not Applicable to BLEED port vALveS.	replace the t ev	
	oversized t ev	install correct t ev	
	incorrect sensing bulb location	install bulb with two mounting straps, in 2:00 or 4:00 position on suction line, with insulation	
	Low superheat adjustment (only applicable to t ev with adjustable superheat setting)	turn superheat adjustment clockwise	
	incorrectly installed, or restricted external equalizer line	remove restriction, or relocate external equalizer	
compressor flood back upon start up	refrigerant drainage from flooded evaporator	install trap riser to the top of the evaporator coil	
	compressor in cold location	install crankcase heater on compressor	
	Any of the causes listed under Symptoms of problem #2	Any of the solutions listed under Solutions of problem #2	

THERMOSTATIC EXPANSION VALVES

SYMPTOMS	POSSIBLE CAUSE	CHECK OR REMEDIES
Superheat is low to normal with low suction pressure	unequal evaporator circuit loading	ensure air flow is equally distributed through evaporator
		ensure proper piston is inserted into r/c BA or r/c HA evaporator coil distributor
	Low load or airflow entering evaporator coil	check for blocked distributor tubes
		ensure blower is moving proper air c/f m
		remove/correct any air flow restriction
Superheat and suction pressure fluctuate (valve is hunting)	expansion valve is oversized	install correct t ev
	Sensing bulb is affected by liquid refrigerant or refrigerant oil flowing through suction line	relocate sensing bulb in another position around the circumference of the suction line
	unequal refrigerant flow through evaporator circuits	ensure proper distributor piston is inserted in r/c BA or r/c HA coil
		ensure sensing bulb is located properly
		check for blocked distributor tubes
improper superheat adjustment (only possible with t ev having superheat adjustment)	replace t ev or adjust superheat	
moisture freezing and partially blocking t ev	recover refrigerant, change filter-drier, evacuate system and recharge	
valve does not regulate at all	external equalizer line not connected or line plugged	connect equalizer line in proper location, or remove any blockage
	Sensing bulb lost its operating charge	replace t ev
	valve body damaged during soldering or by improper installation	replace t ev

17.0 WIRING DIAGRAMS

FIGURE 6
WIRING DIAGRAM



<p>COMPONENT CODE</p> <p>CC COMPRESSOR CONTACTOR CCH CRANKCASE HEATER CHC CRANKCASE HEATER CONTROL COMP COMPRESSOR DFC DEFROST CONTROL DS DEFROST SENSOR GND GROUND, CHASSIS HPC HIGH PRESSURE CUT-OUT CONTROL LAC LOW AMBIENT COOLING CONTROL LAR LOW AMBIENT RELAY LPC LOW PRESSURE CUT-OUT CONTROL OFM OUTDOOR FAN MOTOR OPT OPTIONAL RC RUN CAPACITOR SC START CAPACITOR SR START RELAY TDC TIME DELAY CONTROL HGS HOT GAS SENSOR PTCR POSITIVE TEMPERATURE COEFFICIENT RELAY RV REVERSING VALVE</p>	<p>NOTES: ⚠</p> <ol style="list-style-type: none"> CONNECTORS SUITABLE FOR USE WITH COPPER CONDUCTORS ONLY. COMPRESSOR MOTOR THERMALLY PROTECTED AND ALL 3 PHASE ARE PROTECTED UNDER PRIMARY SINGLE PHASE CONDITIONS. CONNECT FIELD WIRING IN GROUNDED RAIN-TIGHT CONDUIT TO 60 HERTZ FUSED DISCONNECT, VOLTAGE AND PHASE PER RATING PLATE. LOW VOLTAGE CIRCUIT TO BE N.E.C. CLASS 2 WITH A CLASS 2 TRANSFORMER 24 VOLT, 60 HERTZ. TO THERMOSTAT SUB-BASE, REFER TO SYSTEM SCHEMATICS OR SCHEMATICS ON INDOOR SECTION FOR LOW VOLTAGE CONTROL WIRING. THIS WIRE IS USED TO TURN ON ELECTRIC RESISTANCE HEAT DURING DEFROST. OMIT CONNECTION FOR MOST ECONOMICAL OPERATION. TO HEAT PUMP MONITOR 2.5 VA, MAX, WHEN USED. THIS COMPONENT IS ENERGIZED IN HEATING MODE. IF LAC/LAR IS NOT USED, CONNECT BLACK WIRE FROM OFM TO FAN TERMINAL ON DEFROST CONTROL. 																				
<p>WIRING INFORMATION</p> <p>LINE VOLTAGE -FACTORY STANDARD _____ -FACTORY OPTION - - - - - -FIELD INSTALLED - - - - -</p> <p>LOW VOLTAGE -FACTORY STANDARD _____ -FACTORY OPTION - - - - - -FIELD INSTALLED - - - - -</p> <p>REPLACEMENT WIRE -MUST BE THE SAME SIZE AND TYPE OF INSULATION AS ORIGINAL (105 °C MIN.) WARNING -CABINET MUST BE PERMANENTLY GROUNDED AND CONFORM TO I.E.C., N.E.C., C.E.C. AND LOCAL CODES AS APPLICABLE.</p>	<p>WIRE COLOR CODE</p> <table> <tr><td>BK__BLACK</td><td>O___ORANGE</td></tr> <tr><td>BR__BROWN</td><td>PR__PURPLE</td></tr> <tr><td>BL__BLUE</td><td>R___RED</td></tr> <tr><td>G___GREEN</td><td>W___WHITE</td></tr> <tr><td>GY__GRAY</td><td>Y___YELLOW</td></tr> </table> <p>WIRING DIAGRAM REMOTE HEAT PUMPS 208/230 VOLT SINGLE PHASE</p> <table border="1"> <tr> <td>DR. BY</td> <td>APP. BY</td> <td>DATE</td> <td>DWG. NO.</td> <td>REV</td> </tr> <tr> <td>JHB</td> <td></td> <td>01-19-04</td> <td>90-101229-02</td> <td>03</td> </tr> </table>	BK__BLACK	O___ORANGE	BR__BROWN	PR__PURPLE	BL__BLUE	R___RED	G___GREEN	W___WHITE	GY__GRAY	Y___YELLOW	DR. BY	APP. BY	DATE	DWG. NO.	REV	JHB		01-19-04	90-101229-02	03
BK__BLACK	O___ORANGE																				
BR__BROWN	PR__PURPLE																				
BL__BLUE	R___RED																				
G___GREEN	W___WHITE																				
GY__GRAY	Y___YELLOW																				
DR. BY	APP. BY	DATE	DWG. NO.	REV																	
JHB		01-19-04	90-101229-02	03																	

