

# ALL-ACCESS

## Model AA3

### Condensate Float Switch

## INSTRUCTIONS

Note: Failure to follow instructions may cause injury or property damage.

- Disconnect power to unit prior to installation, servicing or cleaning.
- Test switch operation at least every three (3) months.
- Place warning label (Included) in visible location.

To Install:

- Place AA3 onto side wall of drain pan. Tighten Thumb Screw so that device is secure to the side of pan.
- Push Switch Bracket down to lowest possible point. NOTE: To Lower Switch even further, if necessary, remove switch from C-clip and reinstall to next groove up on switch.

WIRING:

- Disconnect power to unit before wiring.
- Add fuse & time delay to protect 24-volt circuit & to prevent excess cycling.
- Connect switch wires in series with either Red or Yellow T-Stat wires.

To Test Switch Operation: Turn unit power on. Lift float to ensure unit shuts off.

**WARNING:** This switch is for extra protection to prevent water damage from an overflow. A pan or other means of protection should be used in addition to this device as described in local codes.

## INSTRUCCIONES

Nota: No seguir las instrucciones puede provocar lesiones o daños a la propiedad.

- Desconectela alimentación a la unidad antes de la instalación, el mantenimiento o la limpieza.
- Probar el funcionamiento del interruptor por lo menos cada tres (3) meses.
- Colocar etiqueta de advertencia (incluido) en lugar visible

Para instalar:

Lugar AA3 en pared lateral de bandeja de drenaje. Apriete el tornillo de mariposa para que dispositivo es seguro para el lado de la bandeja.

Pulsar el interruptor del soporte para hacer punto más bajo posible. NOTA: Para Control de descenso aún más, si es necesario, quite el interruptor de C-clip y volver a instalar a la siguiente ranura hacia arriba en el interruptor.

CABLEADO:

- Desconecte la alimentación a la unidad antes de.
- Agregar fusible y retardo de tiempo para proteger 24 voltios y circuito para evitar un exceso de activación.
- Conectar los cables del interruptor en serie con color rojo o amarillo T-Stat cables.

Para probar el funcionamiento del interruptor: Apague la unidad. Levante la flotación para asegúrese de que la unidad se apaga.