



# RBHM

Parts List  
27-February-2014



*This parts list is current as of the above revision date.  
See <http://www.rheempartslists.net/92-42800-RBHM.pdf> for the current revision.*

**Air Handlers**

# Table of Contents

Model Explanation ..... Page 3

## Parts Numbers

Panels - Coil 17 .....	Page 4
Panels - Coil 17-24 .....	Page 5
Panels - Coil 24-25 .....	Page 6
Panels - Coil 25-26 .....	Page 7
Panel - Coils 26 .....	Page 8
Blower Group 17-25 .....	Page 9
Blower Group 25-26 .....	Page 10
Electrical Group 17-25 .....	Page 11
Electrical Group 25-26 .....	Page 12

## Drawings/Photographs

Notes/Disclaimer ..... Page 13

**MODEL NUMBER EXPLANATION**

<b>R</b>	<b>B</b>	<b>H</b>	<b>M</b>	<b>-</b>	<b>1</b>	<b>7</b>	<b>J</b>	<b>1</b>	<b>1</b>	<b>S</b>	<b>M</b>	<b>Q</b>
(1)	(2)	(3)	(4)		(5)		(6)	(7)		(8)	(9)	(10)

- |  |  |
|--|--|
| <p><b>(1) TRADEBRAND IDENTIFICATION</b></p> <p><b>(2) B = BLOWER UNIT</b></p> <p><b>(3) H = HEAT PUMP AIR HANDLER</b></p> <p><b>(4) M = ECM MOTOR 16 SEER R-410A</b></p> <p><b>(5) CABINET WIDTH</b><br/>         17= 17.5" Cabinet (640-800 CFM)<br/>         24= 24.5" Cabinet (960-1250 CFM)<br/>         25= 24.5" Cabinet (1400-1600 CFM)<br/>         26= 24.5" Cabinet (1600-1800 CFM)</p> <p><b>(6) ELECTRICAL DESIGNATIONS</b><br/>         J= 208/240 VOLT, 1 PHASE, 60 HZ</p> | <p><b>(7) ELECTRICAL HEAT DESIGNATION</b><br/>         Number = Nominal Electric Heat (K.W.)<br/>         00= NO HEAT<br/>         06= 4.9 KW<br/>         07= 7.0 KW<br/>         11= 10.0 KW<br/>         14= 14.0 KW<br/>         18= 17.5 KW<br/>         21= 21.0 KW</p> <p><b>(8) CONTROL DESIGNATIONS</b><br/>         N= No Circuit Breakers, Single Supply Circuit<br/>         S=Circuit Breakers, Single Supply Circuit</p> <p><b>(9) AIRFLOW/CONNECTION (REFRIGERANT)</b><br/>         M= Multi Position Front/Horizontal (L/R)</p> <p><b>(10) COIL CODE</b><br/>         Q= RCQD-2417AS<br/>         R= RCQD-3624AS<br/>         S= RCQD-4824AS<br/>         T= RCQD-6024AS</p> |
|--|--|

**SERIAL NUMBER EXPLANATION**

<b>T</b>	<b>M</b>	<b>1</b>	<b>5</b>	<b>9</b>	<b>7</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>
(1)	(2)	(3)		(4)		(5)				

- (1) SEQUENCE MANUFACTURER**  
 T = THERM-O-DISC  
 Blank = No Sequencer
- (2) PRODUCTION LOCATION**  
 M = MILLEDGEVILLE
- (3) WEEK OF MANUFACTURE**
- (4) YEAR OF MANUFACTURE**
- (5) PRODUCTION NUMBER**

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	17	17	17	17	17
		ELECTRIC HEAT	00	06	06	07	07
		CONTROL	N	N	S	N	S
		COIL CODE	Q	Q	Q	Q	Q
<b>PANELS, MISCELLANEOUS PARTS</b>							
		Jacket Assy - Bent (Gray)	AE-103178-32	N/A	AE-103178-32	N/A	N/A
		Jacket Assy - Bent (Green)	AS-58397-02	AS-58397-02	AS-58397-02	AS-58397-02	AS-58397-02
		Blower Shelf/Cvr Assy	AS-58389-05	AS-58389-05	AS-58389-05	AS-58389-05	AS-58389-05
		Botton Channel	AE-58381-02	AE-58381-02	AE-58381-02	AE-58381-02	AE-58381-02
		Blower Door (Gray)	AE-59440-45	N/A	AE-59440-46	N/A	N/A
		Blower Door (Green)	AE-59440-05	AE-59440-06	AE-59440-06	AE-59440-05	AE-59440-06
		Circuit Brkr Cover Assy	68-101808-01	68-101808-01	68-101808-01	68-101808-01	68-101808-01
		Rear Blower Support	AE-58349-05	AE-58349-05	AE-58349-05	AE-58349-05	AE-58349-05
		Coil Door Assy	AS-100068-56	AS-100068-56	AS-100068-56	AS-100068-56	AS-100068-56
		Channel - Side Coil Support	AE-100009-01	AE-100009-01	AE-100009-01	AE-100009-01	AE-100009-01
		Channel - Rear Coil Support	AE-100010-01	AE-100010-01	AE-100010-01	AE-100010-01	AE-100010-01
		Blockoff Plate	AS-59320-01	AS-59320-01	AS-59320-01	AS-59320-01	AS-59320-01
		Center Panel	AE-58385-02	AE-58385-02	AE-58385-04	AE-58385-02	AE-58385-04
	Stk	Drain Pan - Vertical	68-100000-01	68-100000-01	68-100000-01	68-100000-01	68-100000-01
	Stk	Drain Pan - Horizontal	68-100002-01	68-100002-01	68-100002-01	68-100002-01	68-100002-01
		Vertical Drainpan Brkt	AE-100029-01	AE-100029-01	AE-100029-01	AE-100029-01	AE-100029-01

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	17	17	17	17	17
		ELECTRIC HEAT	00	06	06	07	07
		CONTROL	N	N	S	N	S
		COIL CODE	Q	Q	Q	Q	Q
<b>COIL GROUP</b>							
<b>NOTE: See the parts list for the specified coil for TXV replacement information.</b>							
	Stk	Cased Coil Assy w/TXV	RCQD-2417AS	RCQD-2417AS	RCQD-2417AS	RCQD-2417AS	RCQD-2417AS
		Strainer	83-26020-02	83-26020-02	83-26020-02	83-26020-02	83-26020-02

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	17	17	24	24	24
		ELECTRIC HEAT	11	11	00	07	07
		CONTROL	N	S	N	N	S
		COIL CODE	Q	Q	R	R	R
<b>PANELS, MISCELLANEOUS PARTS</b>							
		Jacket Assy - Bent (Gray)	N/A	AE-103178-32	AE-103178-34	N/A	AE-103178-34
		Jacket Assy - Bent (Green)	AS-58397-02	AS-58397-02	AS-58397-04	AS-58397-04	AS-58397-04
		Blower Shelf/Cvr Assy	AS-58389-05	AS-58389-05	AS-58389-07	AS-58389-07	AS-58389-07
		Botton Channel	AE-58381-01	AE-58381-01	AE-58381-04	AE-58381-04	AE-58381-04
		Blower Door (Gray)	N/A	AE-59440-46	AE-59442-45	N/A	AE-59442-46
		Blower Door (Green)	AE-59440-05	AE-59440-06	AE-59442-05	AE-59442-05	AE-59442-06
		Circuit Brkr Cover Assy	68-101808-01	68-101808-01	68-101808-01	68-101808-01	68-101808-01
		Rear Blower Support	AE-58349-05	AE-58349-05	AE-58349-06	AE-58349-06	AE-58349-06
		Coil Door Assy	AS-100068-56	AS-100068-56	AS-100068-58	AS-100068-58	AS-100068-58
		Channel - Side Coil Support	AE-100009-01	AE-100009-01	AE-100009-01	AE-100009-01	AE-100009-01
		Channel - Rear Coil Support	AE-100010-01	AE-100010-01	AE-100010-03	AE-100010-03	AE-100010-03
		Blockoff Plate	AS-59320-01	AS-59320-01	AS-59320-01	AS-59320-01	AS-59320-01
		Center Panel	AE-58385-02	AE-58385-04	AE-58385-14	AE-58385-14	AE-58385-16
	Stk	Drain Pan - Vertical	68-100000-01	68-100000-01	68-100000-03	68-100000-03	68-100000-03
	Stk	Drain Pan - Horizontal	68-100002-01	68-100002-01	68-100002-01	68-100002-01	68-100002-01
		Vertical Drainpan Brkt	AE-100029-01	AE-100029-01	AE-100029-01	AE-100029-01	AE-100029-01

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	17	17	24	24	24
		ELECTRIC HEAT	11	11	00	07	07
		CONTROL	N	S	N	N	S
		COIL CODE	Q	Q	R	R	R
<b>COIL GROUP</b>							
<b>NOTE: See the parts list for the specified coil for TXV replacement information.</b>							
	Stk	Cased Coil Assy w/TXV	RCQD-2417AS	RCQD-2417AS	RCQD-3624AS	RCQD-3624AS	RCQD-3624AS
		Strainer	83-26020-02	83-26020-02	83-26020-02	83-26020-02	83-26020-02

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	24	24	24	25	25
		ELECTRIC HEAT	11	11	14	00	11
		CONTROL	N	S	S	N	N
		COIL CODE	R	R	R	S	S
<b>PANELS, MISCELLANEOUS PARTS</b>							
		Jacket Assy - Bent (Gray)	N/A	AE-103178-34	AE-103178-34	AE-103178-34	N/A
		Jacket Assy - Bent (Green)	AS-58397-04	AS-58397-04	AS-58397-04	AS-58397-04	AS-58397-04
		Blower Shelf/Cvr Assy	AS-58389-07	AS-58389-07	AS-58389-07	AS-58389-04	AS-58389-04
		Botton Channel	AE-58381-04	AE-58381-04	AE-58381-04	AE-58381-04	AE-58381-04
		Blower Door (Gray)	N/A	AE-59442-46	AE-59442-47	AE-59442-45	N/A
		Blower Door (Green)	AE-59442-05	AE-59442-06	AE-59442-07	AE-59442-05	AE-59442-05
		Circuit Brkr Cover Assy	68-101808-01	68-101808-01	68-101808-01	68-101808-01	68-101808-01
		Rear Blower Support	AE-58349-06	AE-58349-06	AE-58349-06	AE-58349-06	AE-58349-06
		Coil Door Assy	AS-100068-08	AS-100068-08	AS-100068-08	AS-100068-08	AS-100068-08
		Channel - Side Coil Support	AE-100009-01	AE-100009-01	AE-100009-01	AE-100009-01	AE-100009-01
		Channel - Rear Coil Support	AE-100010-03	AE-100010-03	AE-100010-03	AE-100010-03	AE-100010-03
		Blockoff Plate	AS-59320-01	AS-59320-01	AS-59320-01	AS-59320-01	AS-59320-01
		Center Panel	AE-58385-14	AE-58385-16	AE-58385-18	AE-58385-24	AE-58385-24
	Stk	Drain Pan - Vertical	68-100000-03	68-100000-03	68-100000-03	68-100000-03	68-100000-03
	Stk	Drain Pan - Horizontal	68-100002-01	68-100002-01	68-100002-01	68-100002-01	68-100002-01
		Vertical Drainpan Brkt	AE-100029-01	AE-100029-01	AE-100029-01	AE-100029-01	AE-100029-01

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	24	24	24	25	25
		ELECTRIC HEAT	11	11	14	00	11
		CONTROL	N	S	S	N	N
		COIL CODE	R	R	R	S	S
<b>COIL GROUP</b>							
<b>NOTE: See the parts list for the specified coil for TXV replacement information.</b>							
	Stk	Cased Coil Assy w/TXV	RCQD-3624AS	RCQD-3624AS	RCQD-3624AS	RCQD-4824AS	RCQD-4824AS
		Strainer	83-26020-02	83-26020-02	83-26020-02	83-26020-02	83-26020-02

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	25	25	25	26	26
		ELECTRIC HEAT	11	14	18	00	11
		CONTROL	S	S	S	N	N
		COIL CODE	S	S	S	T	T
<b>PANELS, MISCELLANEOUS PARTS</b>							
		Jacket Assy - Bent (Gray)	AE-103178-34	AE-103178-34	AE-103178-34	AE-103178-34	N/A
		Jacket Assy - Bent (Green)	AS-58397-04	AS-58397-04	AS-58397-04	AS-58397-04	AS-58397-04
		Blower Shelf/Cvr Assy	AS-58389-04	AS-58389-04	AS-58389-04	AS-58389-04	AS-58389-04
		Botton Channel	AE-58381-04	AE-58381-04	AE-58381-04	AE-58381-04	AE-58381-04
		Blower Door (Gray)	AE-59442-46	AE-59442-47	AE-59442-47	AE-59442-45	N/A
		Blower Door (Green)	AE-59442-06	AE-59442-07	AE-59442-27	AE-59442-05	AE-59442-05
		Circuit Brkr Cover Assy	68-101808-01	68-101808-01	68-101808-01	68-101808-01	68-101808-01
		Rear Blower Support	AE-58349-06	AE-58349-06	AE-58349-06	AE-58349-06	AE-58349-06
		Coil Door Assy	AS-100068-08	AS-100068-08	AS-100068-08	AS-100068-08	AS-100068-08
		Channel - Side Coil Support	AE-100009-01	AE-100009-01	AE-100009-01	AE-100009-01	AE-100009-01
		Channel - Rear Coil Support	AE-100010-03	AE-100010-03	AE-100010-03	AE-100010-03	AE-100010-03
		Blockoff Plate	AS-59320-01	AS-59320-01	AS-59320-01	AS-59320-01	AS-59320-01
		Center Panel	AE-58385-24	AE-58385-24	AE-58385-24	AE-58385-24	AE-58385-24
	Stk	Drain Pan - Vertical	68-100000-03	68-100000-03	68-100000-03	68-100000-03	68-100000-03
	Stk	Drain Pan - Horizontal	68-100002-01	68-100002-01	68-100002-01	68-100002-01	68-100002-01
		Vertical Drainpan Brkt	AE-100029-01	AE-100029-01	AE-100029-01	AE-100029-01	AE-100029-01

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	25	25	25	26	26
		ELECTRIC HEAT	11	14	18	00	11
		CONTROL	S	S	S	N	N
		COIL CODE	S	S	S	T	T
<b>COIL GROUP</b>							
<b>NOTE: See the parts list for the specified coil for TXV replacement information.</b>							
	Stk	Cased Coil Assy w/TXV	RCQD-4824AS	RCQD-4824AS	RCQD-4824AS	RCQD-6024AS	RCQD-6024AS
		Strainer	83-26020-02	83-26020-02	83-26020-02	83-26020-01	83-26020-01

No.	Notes	MODEL CABINET SIZE ELECTRIC HEAT CONTROL COIL CODE	RBHM	RBHM	RBHM	RBHM
			26 11 S T	26 14 S T	26 18 S T	26 21 S T
<b>PANELS, MISCELLANEOUS PARTS</b>						
		Jacket Assy - Bent (Gray)	AE-103178-34	AE-103178-34	N/A	AE-103178-34
		Jacket Assy - Bent (Green)	AS-58397-04	AS-58397-04	AS-58397-04	AS-58397-04
		Blower Shelf/Cvr Assy	AS-58389-04	AS-58389-04	AS-58389-04	AS-58389-04
		Botton Channel	AE-58381-04	AE-58381-04	AE-58381-04	AE-58381-04
		Blower Door (Gray)	AE-59442-46	AE-59442-47	N/A	AE-59442-47
		Blower Door (Green)	AE-59442-06	AE-59442-07	AE-59442-27	AE-59442-07
		Circuit Brkr Cover Assy	68-101808-01	68-101808-01	68-101808-01	68-101808-01
		Rear Blower Support	AE-58349-06	AE-58349-06	AE-58349-06	AE-58349-06
		Coil Door Assy	AS-100068-08	AS-100068-08	AS-100068-08	AS-100068-08
		Channel - Side Coil Support	AE-100009-01	AE-100009-01	AE-100009-01	AE-100009-01
		Channel - Rear Coil Support	AE-100010-03	AE-100010-03	AE-100010-03	AE-100010-03
		Blockoff Plate	AS-59320-01	AS-59320-01	AS-59320-01	AS-59320-01
		Center Panel	AE-58385-24	AE-58385-24	AE-58385-24	AE-58385-26
	Stk	Drain Pan - Vertical	68-100000-03	68-100000-03	68-100000-03	68-100000-03
	Stk	Drain Pan - Horizontal	68-100002-01	68-100002-01	68-100002-01	68-100002-01
		Vertical Drainpan Brkt	AE-100029-01	AE-100029-01	AE-100029-01	AE-100029-01

No.	Notes	MODEL CABINET SIZE ELECTRIC HEAT CONTROL COIL CODE	RBHM	RBHM	RBHM	RBHM
			26 11 S T	26 14 S T	26 18 S T	26 21 S T
<b>COIL GROUP</b>						
<b>NOTE: See the parts list for the specified coil for TXV replacement information.</b>						
	Stk	Cased Coil Assy w/TXV	RCQD-6024AS	RCQD-6024AS	RCQD-6024AS	RCQD-6024AS
		Strainer	83-26020-01	83-26020-01	83-26020-01	83-26020-01



No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	17	17	17	17	17
		ELECTRIC HEAT	00	06	06	07	07
		CONTROL	N	N	S	N	S
		COIL CODE	Q	Q	Q	Q	Q
<b>BLOWER GROUP</b>							
		Blower Housing	AS-58391-01	AS-58391-23	AS-58391-23	AS-58391-03	AS-58391-03
		Air Straightner	AE-58392-02	AE-58392-02	AE-58392-02	AE-58392-02	AE-58392-02
	Stk	Blower Wheel	70-23111-50	70-23111-50	70-23111-50	70-23111-50	70-23111-50
		ICM Motor Mount	70-24104-01	70-24104-01	70-24104-01	70-24104-01	70-24104-01
		Motor Mount Bracket	AE-61956-02	AE-61956-02	AE-61956-02	AE-61956-02	AE-61956-02
		Mounting Bracket	AE-90898-01	AE-90898-01	AE-90898-01	AE-90898-01	AE-90898-01
	Stk	Motor (ECM) - Motor and Module	51-24373-05	51-24373-05	51-24373-05	51-24373-05	51-24373-05
		Filter Base	54-1620-E3	54-1620-E3	54-1620-E3	54-1620-E3	54-1620-E3

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	17	17	24	24	24
		ELECTRIC HEAT	11	11	00	07	07
		CONTROL	N	S	N	N	S
		COIL CODE	Q	Q	R	R	R
<b>BLOWER GROUP</b>							
		Blower Housing	AS-58391-04	AS-58391-04	AS-58391-10	AS-58391-12	AS-58391-12
		Air Straightner	AE-58392-02	AE-58392-02	AE-58392-02	AE-58392-02	AE-58392-02
	Stk	Blower Wheel	70-23111-50	70-23111-50	70-23111-43	70-23111-43	70-23111-43
		ICM Motor Mount	70-24104-01	70-24104-01	70-24104-01	70-24104-01	70-24104-01
		Motor Mount Bracket	AE-61956-02	AE-61956-02	AE-61956-02	AE-61956-02	AE-61956-02
		Mounting Bracket	AE-90898-01	AE-90898-01	AE-90898-01	AE-90898-01	AE-90898-01
	Stk	Motor (ECM) - Motor and Module	51-24373-05	51-24373-05	51-24374-16	51-24374-16	51-24374-16
		Filter Base	54-1620-E3	54-1620-E3	54-2025-E3	54-2025-E3	54-2025-E3

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	24	24	24	25	25
		ELECTRIC HEAT	11	11	14	00	11
		CONTROL	N	S	S	N	N
		COIL CODE	R	R	R	S	S
<b>BLOWER GROUP</b>							
		Blower Housing	AS-58391-13	AS-58391-13	AS-58391-14	AS-58391-16	AS-58391-19
		Air Straightner	AE-58392-02	AE-58392-02	AE-58392-02	AE-58392-02	AE-58392-02
	Stk	Blower Wheel	70-23111-43	70-23111-43	70-23111-43	70-23111-44	70-23111-44
		ICM Motor Mount	70-24104-01	70-24104-01	70-24104-01	70-24104-01	70-24104-01
		Motor Mount Bracket	AE-61956-02	AE-61956-02	AE-61956-02	AE-61956-02	AE-61956-02
		Mounting Bracket	AE-90898-01	AE-90898-01	AE-90898-01	AE-90898-01	AE-90898-01
	Stk	Motor (ECM) - Motor and Module	51-24374-16	51-24374-16	51-24374-16	51-24375-10	51-24375-10
		Filter Base	54-2025-E3	54-2025-E3	54-2025-E3	54-2025-E3	54-2025-E3

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	RBHM
		CABINET SIZE	25	25	25	26	26
		ELECTRIC HEAT	11	14	18	00	11
		CONTROL	S	S	S	N	N
		COIL CODE	S	S	S	T	T
<b>BLOWER GROUP</b>							
		Blower Housing	AS-58391-19	AS-58391-20	AS-58391-21	AS-58391-16	AS-58391-19
		Air Straightner	AE-58392-02	AE-58392-02	AE-58392-02	AE-58392-02	AE-58392-02
	Stk	Blower Wheel	70-23111-44	70-23111-44	70-23111-44	70-23111-44	70-23111-44
		ICM Motor Mount	70-24104-01	70-24104-01	70-24104-01	70-24104-01	70-24104-01
		Motor Mount Bracket	AE-61956-02	AE-61956-02	AE-61956-02	AE-61956-02	AE-61956-02
		Mounting Bracket	AE-90898-01	AE-90898-01	AE-90898-01	AE-90898-01	AE-90898-01
	Stk	Motor (ECM) - Motor and Module	51-24375-10	51-24375-10	51-24375-10	51-24376-17	51-24376-17
		Filter Base	54-2025-E3	54-2025-E3	54-2025-E3	54-2025-E3	54-2025-E3

No.	Notes	MODEL	RBHM	RBHM	RBHM	RBHM	
		CABINET SIZE	26	26	26	26	
		ELECTRIC HEAT	11	14	18	21	
		CONTROL	S	S	S	S	
		COIL CODE	T	T	T	T	
<b>BLOWER GROUP</b>							
		Blower Housing	AS-58391-19	AS-58391-20	AS-58391-21	AS-58391-22	
		Air Straightner	AE-58392-02	AE-58392-02	AE-58392-02	AE-58392-02	
	Stk	Blower Wheel	70-23111-44	70-23111-44	70-23111-44	70-23111-44	
		ICM Motor Mount	70-24104-01	70-24104-01	70-24104-01	70-24104-01	
		Motor Mount Bracket	AE-61956-02	AE-61956-02	AE-61956-02	AE-61956-02	
		Mounting Bracket	AE-90898-01	AE-90898-01	AE-90898-01	AE-90898-01	
	Stk	Motor (ECM) - Motor and Module	51-24376-17	51-24376-17	51-24376-17	51-24376-17	
		Filter Base	54-2025-E3	54-2025-E3	54-2025-E3	54-2025-E3	

No.	Notes	MODEL CABINET SIZE ELECTRIC HEAT CONTROL COIL CODE	RBHM	RBHM	RBHM	RBHM	RBHM
			17 00 N Q	17 06 N Q	17 06 S Q	17 07 N Q	17 07 S Q
<b>ELECTRICAL GROUP</b>							
		Terminal Block	45-23222-01	45-23222-02	N/A	45-23222-02	N/A
	Stk	Transformer	46-23115-02	46-23115-02	46-23115-02	46-23115-02	46-23115-02
	Stk	ECM Interface Control	62-24340-03	62-24340-03	62-24340-03	62-24340-03	62-24340-03
		Plug Housing - Low Voltage	45-24258-10	45-24258-10	45-24258-10	45-24258-10	45-24258-10
		Wire Harness - High Voltage	45-24258-02	45-24258-02	45-24258-02	45-24258-02	45-24258-02
		Circuit Breaker	N/A	N/A	42-23201-01	N/A	42-23201-01
	Stk	Sequencing Relay(s)	N/A	N/A	N/A	N/A	N/A
	Stk	Sequencing Relay(s)	N/A	42-23116-06	42-23116-06	42-23116-09	42-23116-09
		Finger Stop	N/A	N/A	45-23203-01 (2)	N/A	45-23203-01 (2)
		Heater/Bracket Assembly	N/A	AS-58386-11	AS-58386-11	AS-58386-12	AS-58386-12

No.	Notes	MODEL CABINET SIZE ELECTRIC HEAT CONTROL COIL CODE	RBHM	RBHM	RBHM	RBHM	RBHM
			17 11 N Q	17 11 S Q	24 00 N R	24 07 N R	24 07 S R
<b>ELECTRICAL GROUP</b>							
		Terminal Block	45-23222-02	N/A	45-23222-01	45-23222-02	N/A
	Stk	Transformer	46-23115-02	46-23115-02	46-23115-02	46-23115-02	46-23115-02
	Stk	ECM Interface Control	62-24340-03	62-24340-03	62-24340-03	62-24340-03	62-24340-03
		Plug Housing - Low Voltage	45-24258-10	45-24258-10	45-24258-10	45-24258-10	45-24258-10
		Wire Harness - High Voltage	45-24258-02	45-24258-02	45-24258-02	45-24258-02	45-24258-02
	Stk	Circuit Breaker	N/A	42-23201-01	N/A	N/A	42-23201-01
	Stk	Sequencing Relay(s)	42-23116-06	42-23116-06	N/A	N/A	N/A
	Stk	Sequencing Relay(s)	42-23116-08	42-23116-08	N/A	42-23116-09	42-23116-09
		Finger Stop	N/A	45-23203-01 (2)	N/A	N/A	45-23203-01 (2)
	Stk	Heater/Bracket Assembly	AS-58386-12	AS-58386-12	N/A	AS-58386-12	AS-58386-12

No.	Notes	MODEL CABINET SIZE ELECTRIC HEAT CONTROL COIL CODE	RBHM	RBHM	RBHM	RBHM	RBHM
			24 11 N R	24 11 S R	24 14 S R	25 00 N S	25 11 N S
<b>ELECTRICAL GROUP</b>							
		Terminal Block	45-23222-02	N/A	N/A	45-23222-01	45-23222-02
	Stk	Transformer	46-23115-02	46-23115-02	46-23115-02	46-23115-02	46-23115-02
	Stk	ECM Interface Control	62-24340-03	62-24340-03	62-24340-03	62-24340-03	62-24340-03
		Plug Housing - Low Voltage	45-24258-10	45-24258-10	45-24258-10	45-24258-10	45-24258-10
		Wire Harness - High Voltage	45-24258-02	45-24258-02	45-24258-02	45-24258-02	45-24258-02
	Stk	Circuit Breaker	N/A	42-23201-01	42-23201-01	N/A	N/A
	Stk	Sequencing Relay(s)	42-23116-06	42-23116-06	42-23116-08	N/A	42-23116-06
	Stk	Sequencing Relay(s)	42-23116-08	42-23116-08	42-23116-09	N/A	42-23116-08
		Finger Stop	N/A	45-23203-01	N/A	N/A	N/A
	Stk	Watt Restrictors	N/A	N/A	47-23117-02	N/A	N/A
		Jumper Bar	N/A	N/A	45-23202-01	N/A	N/A
	Stk	Defrost Heater Control	N/A	N/A	47-23118-01	N/A	N/A
	Stk	Heater/Bracket Assembly	AS-58386-12	AS-58386-12	AS-58386-12	N/A	AS-58386-12

No.	Notes	MODEL CABINET SIZE ELECTRIC HEAT CONTROL COIL CODE	RBHM	RBHM	RBHM	RBHM	RBHM
			25 11 S S	25 14 S S	25 18 S S	26 00 N T	26 11 N T
<b>ELECTRICAL GROUP</b>							
		Terminal Block	N/A	N/A	N/A	45-23222-01	45-23222-02
	Stk	Transformer	46-23115-02	46-23115-02	46-23115-02	46-23115-02	46-23115-02
	Stk	ECM Interface Control	62-24340-03	62-24340-03	62-24340-03	62-24340-03	62-24340-03
		Plug Housing - Low Voltage	45-24258-10	45-24258-10	45-24258-10	45-24258-10	45-24258-10
		Wire Harness - High Voltage	45-24258-02	45-24258-02	45-24258-02	45-24258-02	45-24258-02
	Stk	Circuit Breaker	42-23201-01	42-23201-01 (2)	42-23201-01 (2)	N/A	N/A
	Stk	Sequencing Relay(s)	42-23116-06	42-23116-08	42-23116-09	N/A	42-23116-06
	Stk	Sequencing Relay(s)	42-23116-08	42-23116-09	42-23116-09	N/A	42-23116-08
		Finger Stop	45-23203-01 (2)	N/A	N/A	N/A	N/A
	Stk	Watt Restrictors	N/A	47-23117-02	47-23117-02	N/A	N/A
		Jumper Bar	N/A	45-23202-01	45-23202-01	N/A	N/A
	Stk	Defrost Heater Control	N/A	47-23118-01	47-23118-01	N/A	N/A
	Stk	Heater/Bracket Assembly	AS-58386-12	AS-58386-12	AS-58386-12	N/A	AS-58386-12

No.	Notes	MODEL CABINET SIZE ELECTRIC HEAT CONTROL COIL CODE	RBHM	RBHM	RBHM	RBHM	
			26 11 S T	26 14 S T	26 18 S T	26 21 S T	
<b>ELECTRICAL GROUP</b>							
		Terminal Block	N/A	N/A	N/A	N/A	
	Stk	Transformer	46-23115-02	46-23115-02	46-23115-02	46-23115-02	
	Stk	ECM Interface Control	62-24340-03	62-24340-03	62-24340-03	62-24340-03	
		Plug Housing - Low Voltage	45-24258-10	45-24258-10	45-24258-10	45-24258-10	
		Wire Harness - High Voltage	45-24258-02	45-24258-02	45-24258-02	45-24258-02	
	Stk	Circuit Breaker	42-23201-01 (1)	42-23201-01 (2)	42-23201-01 (2)	42-23201-01 (2)	
	Stk	Sequencing Relay(s)	42-23116-06	42-23116-08	42-23116-09	42-23116-09	
	Stk	Sequencing Relay(s)	42-23116-08	42-23116-09	42-23116-09	42-23116-09	
		Finger Stop	45-23203-01 (2)	N/A	N/A	N/A	
	Stk	Watt Restrictors	N/A	47-23117-02	47-23117-02	47-23117-02	
		Jumper Bar	N/A	45-23202-01	45-23202-01	45-23202-01	
	Stk	Defrost Heater Control	N/A	47-23118-01	47-23118-01	47-23118-01	
	Stk	Heater/Bracket Assembly	AS-58386-12	AS-58386-12	AS-58386-12	AS-58386-12	

# NOTES

Stk It is recommended that stock be maintained for this part.  
N/A Not Applicable

**DISCLAIMER:** This document is intended to provide general replacement parts information to aid qualified service personnel in the repair of these models. The complete Model and Serial Number of the unit under repair should be specified when selecting and ordering replacement parts. Specifications and illustrations are subject to change without notice. Document 92-42800-RBHM supersedes all previous parts lists for these models. See <http://www.rheempartslists.net/92-42800-RBHM> for the latest revision of this document. The manufacturer assumes no obligation for errors or omissions. Service personnel must verify the proper and safe operation of equipment after the replacement of any original components.