


# INSTALLATION INSTRUCTIONS

## (-)XRX-AAD01K LOUVER PANEL

### For KKL/LKL- B180/240

 Recognize this symbol as an indication of Important Safety Information!

#### WARNING

THESE INSTRUCTIONS ARE INTENDED AS AN AID TO QUALIFIED SERVICE PERSONNEL FOR PROPER INSTALLATION, ADJUSTMENT, AND OPERATION OF THIS KIT. READ THESE INSTRUCTIONS THOROUGHLY BEFORE ATTEMPTING INSTALLATION, ADJUSTMENT, OR OPERATION. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN IMPROPER INSTALLATION, ADJUSTMENT, SERVICE OR MAINTENANCE, POSSIBLY RESULTING IN FIRE, ELECTRICAL SHOCK, PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH.

#### WARNING

BEFORE BEGINNING ANY MODIFICATION, BE SURE MAIN DISCONNECT SWITCH IS IN THE "OFF" POSITION. FAILURE TO DO SO CAN CAUSE ELECTRICAL SHOCK RESULTING IN PROPERTY DAMAGE, PERSONAL INJURY OR DEATH. TAG DISCONNECT WITH A SUITABLE WARNING LABEL.

#### PARTS LIST

DESCRIPTION	PART NUMBER	QTY
Left Louver Panel Assembly	AS-90789-05	1
Right Louver Panel Assembly	AS-90789-06	1
Mounting Screws	63-42109-03	21

#### TOOLS/SUPPLIES REQUIRED

- 5/16" nut driver.
- Box Cutter (to open packaging).
- Scratch Awl.

#### LOUVER PANEL INSTALLATION PROCEDURE

- Remove louver panels from box.
- When facing the outdoor coil of the unit, install the left louver panel on the front of the unit. Insert a couple of screws to temporarily retain it.
- Install the right louver panel on the front of the unit. Insert the remaining screws and secure panel per the illustration.

