

Quick Start Guide

1) Download iManifoldTM App from Apple App Store or Google Play (Phone/Tablet, Android 4.1 or later, iOS 6.1 or later, iPhone 4S & above or iPad 3 & above)





-Or-




2) Pair & Connect to iManifold Device









iManifold™ App Home Screen



Superheat Scale Target superheat (+/- 5°F) depicted in yellow & green center band per ACCA-QI quidelines

••••0

Target Suction Pressure Appears when system is profiled. Dynamic indicator displays target saturation (+/- 3°F)

R410A 13 SEER, TXV Refrigerant Quick Select R22 R134a R410A 43.869 12.86 13.56

Tap to change refrigerant

App available on Google Play and Apple App Store Search 'iManifold' or use QR codes on other side

Discharge Line Temperature Scale Max 225°F monitor to protect against oil failure

Main Menu Profiling, User Inputs, System Performance



Vacuum Indicator (not microns)


Touch screen to easily map probes to assigned locations

Temperature Inputs Suction Line Temp, Liquid Line Temp, Discharge Line Temp, Outdoor Air Temp all remappable to wired probes. Values change color when streamed in via Bluetooth & overrides user Input.

Evaporator Temperatures Supply Air Dry Bulb, Supply Air Wet Bulb, Return Air Dry Bulb, Return Air Wet Bulb

Calculated Targets Target Suction Pressure, Target Superheat, Target Subcooling, Target High Pressure when system is profiled

Capacity & Efficiency Cooling tons, BTU/hr. kW. EER shown only when all required user inputs are added









Settings Menu Includes connection button to connect app to iManifold device via Bluetooth

Target High/Head Pressure Appears when system is profiled. Dynamic indicator displays target saturation (+/- 3°F)

Subcooling Scale Target subcooling (+/- 3°F) depicted in yellow & orange center band per ACCA-QI quidelines

> **Dynamic Range** Max scale depending on refrigerant selected. Overload pressures displayed on bands.



